



Restoring the CabPay Pro Reader

1. Unlock the terminal from the cradle



- a. Insert the allen key into the screw hole as shown.
- b. Turn the allen screw 2-3 turns **CLOCKWISE** to undo the catch.

2. Remove the terminal from the cradle




- a. Slide the catch on top to the left.
- b. Pull out the device.

3. Restore the terminal




- Insert a pin or paperclip into the tiny hole next to the charging port on the top of the reader.
- Press the green tick.
- Press 2 for System Restore.
NEVER press 3 for Factory reset as it will make your device permanently unusable.
- After a few minutes the device will be reset and you should proceed with PAIRING.

4. How to re-insert the terminal to the cradle



- Insert the bottom of the terminal into the cradle.
- Push the top of the terminal into the cradle so it clicks.

5. How to lock the terminal into the cradle



- a. Slide the catch to the right.
- b. Insert the allen key into the top of the cradle catch.
- c. Turn the allen key clockwise 2-3 turns to lock the terminal in place.